



Samsung WB350F Battery Replacement

This guide will walk you through replacing the battery in your camera.

Written By: Taylor Joubert



INTRODUCTION

In two easy steps, this guide will show you how to replace the battery in your camera if it is no longer working.

Step 1 — Battery



- Open the camera battery terminal that can be found on lower right corner of the camera.

Step 2



- Pull the clip off and take out the old battery, and replace it with the new battery.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-02 07:42:05 PM.